



## Antaira Technologies

### LMX-1802G-M12-10G-SFP-67-110 Series

18-Port Industrial M12 IP67 Waterproof Gigabit Light Layer 3 Managed Ethernet Switch, with 16\*10/100/1000Tx M12 Connectors (X-Coded) and 2\*1G/10G SFP Slots, 24-110VDC Power Input

### Quick Installation Guide

Version 1.0  
(October 2021)




Tel: 1-844-268-2472  
Fax: 1-714-671-9944  
www.antaira.com

### Package Check List

The package contains the following items:

- 1 – Quick Installation Guide
- 1 – LMX-1802G-M12-10G-SFP-67-110(-T)
- 1 – Dust Cover Set
- 2 – SFP Metal Field Installable Cable End Lock
- 1 – SFP Removal Kit

### Front Panel Layout



1	Power 1, Power 2, Status, Master, Ring	7	DI/DO Port
2	Port 1~16 Link/Active Status 10/100/1000 Mbps	8	Power Input Port
3	Port 17~18 SFP Link/Active Status 1G/10Gbps	9	1G/10G SFP+ Port
4	10/100/1000Base-T(X) Ethernet Port	10	Mounting hole
5	Console Port	11	Grounding screw
6	USB Port		

### Product Overview

#### System Interface/Performance

- All Ethernet ports support the auto MDI/MDI-X function
- M12 connector with IP67 rated protection
- Store-and-forward switching architecture

#### Power Input & Connection

- DC 24 to 110V redundant power
- It is recommended to use a UL listed industrial power supply

#### Operating Temperature

- Standard operating temperature model: -10°C to 65°C
- Extended operating temperature model: -40°C to 70°C

#### Case/Installation

- IP67 protection
- Wall Mount design


### LED Indicators

LED	Color	Description	
P1	Green	On	Power input 1 is active
		Off	Power input 1 is inactive
P2	Green	On	Power input 2 is active
		Off	Power input 2 is inactive
Status	Green	On	No event happened after the last reset or reboot
	Red	On	1. System booting 2. Event happened by software setting
		Flashing	Firmware Upgrade
Master	Green	On	ERPS Owner Mode (Ring Master) is ready
		Off	ERPS Owner Mode is not active
Ring	Green	On	ERPS Ring Network is active and work well
		Flashing	ERPS Ring works abnormally or misconfigure
		Off	ERPS Ring Network is not active
LINK/ACT (Port 1~16)	Green	On	Connected to network, 1000 Mbps
		Flashing	Networking is active
		Off	Not connected to network
	Amber	On	Connected to network, 10/100 Mbps
		Flashing	Networking is active
LINK/ACT (SFP Port 17~18)	Green	On	Connected to the network, 10Gbps
		Flashing	Networking is active
		Off	Not connected to network
	Amber	On	Connected to the network, 1Gbps
		Flashing	Networking is active
		Off	Not connected to network

Quick Installation

Ethernet Ports  
M12 Ports (Auto MDI/MDI-X)


All M12 ports (8-Pin X-Coded Female Connector) are auto-sensing for 10Base-T, 100Base-TX, or 1000Base-T device connections. Please follow the wiring pin assignment table below for Ethernet port installation.

Illustration	Pinouts	10/100Base-T(X) Signal	1000Base-T Signal
	1	Transmit Data + (TX+)	BI_DA+
	2	Transmit Data - (TX-)	BI_DA-
	3	Receive Data + (RX+)	BI_DB+
	4	Receive Data - (RX-)	BI_DB-
	5		BI_DD+
	6		BI_DD-
	7		BI_DC-
	8		BI_DC+

NOTE: Recommended use the wire gauge between 18AWG.

Power Input Wiring


- Dual DC power inputs for power redundancy
- Connection format: M12 5-Pin K-Coded male connector
- Pin assignment of M12 power connector:

Illustration	Pinouts	Function
	1	Power Input 1 + (V1+)
	2	Power Input 1 - (V1-)
	3	Power Input 2 - (V2-)
	4	Power Input 2 + (V2+)
	5	GND

NOTE: Recommended use the wire gauge between 24AWG.


Console Port

- Connection format: M12 5-Pin A-Coded Female Connector
- Baud rate 115,200bps, 8, N, 1

Illustration	Pinouts	Signal
	1	NC
	2	TX
	3	RX
	4	NC
	5	GND


USB Port

- Connection format: M12 4-Pin A-Coded Female Connector
- USB Port is for configuration backup / restore

Illustration	Pinouts	Function
	1	DN
	2	VBUS
	3	GND
	4	DP

Relay Contact and Digital Input

- Connection format: M12 5-Pin A-Coded Male Connector
- Minimum Wire Gauge: 24AWG

Illustration	Pinouts	Function	Function
	1	DI+ Relay Com	Common
	2	DI+	Digital Input +
	3	DI-	Digital Input -
	4	DI- Relay (N.C.)	Normally Closed
	5	NA	Not Assigned

- Digital Input (DI)  
The digital input is used for monitoring two external events via an external voltage source. When the voltage level on digital input pins changes from high voltage to low voltage, the DI function will be triggered. Below table is shown a detail specification of the digital input.

Specification		Description
Level 0 (Low)	-30~8VDC	Will trigger DI function (active trigger states)
Level 1 (High)	10~30VDC	Normal Status (inactive trigger states)
Nominal input voltage	24VDC	
Max. input voltage	30VDC	
Nominal input current	5mA (typical)	
Max. input current	8mA	


Reset to Default

Please perform the below steps to reset the switch to factory default setting.


- Step 1.** Reverse the Tx & Rx of the Console Cable and plug it into the console port.
- Step 2.** Restart the power.
- Step 3.** The switch will start rebooting with the port LEDs flashing.
- Step 4.** When the Status LED turns into Green, the process is completed.
- Step 5.** Remove the reversed console cable.

Bypass Function

This Ethernet switch supports bypass function by two Ethernet ports (8 and 16). When one of the Ethernet switches loses power, Ethernet ports (8 and 16) will bypass the power lost Ethernet switch to prevent the network from disconnecting.




SFP Installation



- Step 1**  
Pull out the SFP module which needs to be replaced.
- Step 2**  
Put the fiber cable through the metal end lock, sealing, and cap.
- Step 3**  
Insert the SFP transceiver into the Metal Panel Lock and tighten and seal all parts.

Wall Mounting Installation

Follow the steps below to mount the switch to a wall using the screw holes.



- Step 1.** Prepare 4 screws for mounting the switch to a wall. (Recommended use the M5 screws.)
- Step 2.** Based on the positions of 4 screw holes on the left and right side of the switch to make 4 screw holes on a wall accordingly.
- Step 3.** Insert the screws through the screw holes on the switch and screw the switch into the wall.
- Step 4.** To remove the switch from the wall, do the opposite from the steps above.

Antaira's Customer Service and Support

- Antaira's Technical Service & Support Centers:
  - + 844-268-2472 (Antaira US Headquarter)
  - + 48-22-862-88-81 (Antaira Europe Office)
  - + 886-2-2218-9733 (Antaira Asia Office)
- Antaira's Web Sites & Repair/Support Emails:
  - [www.antaira.com](http://www.antaira.com) / [support@antaira.com](mailto:support@antaira.com)
  - [www.antaira.eu](http://www.antaira.eu) / [info@antaira.eu](mailto:info@antaira.eu)
  - [www.antaira.com.tw](http://www.antaira.com.tw) / [info@antaira.com.tw](mailto:info@antaira.com.tw)

\*Any changes will be announced on the Antaira website.